



General Suppliers

Cast Iron Globe Valve - BS 5152 PN16 **MV50-1211**

Installation & Maintenance Instructions

CE MARKING AND THE PRESSURE EQUIPMENT DIRECTIVE 97/23/EC

This has been implemented in United Kingdom law by the Pressure Equipment Regulations 1999 (SI 1999/2001).

The regulations apply to all valves with a maximum allowable pressure greater than 0.5 bar.

Valves with a maximum allowable pressure not exceeding 0.5 bar are outside the scope of the Directive.

Valves are categorized in accordance with the maximum working pressure, size and ascending level of hazard, which is dependent on the fluid being transported.

Fluids are classified as Group 1, dangerous fluids or Group 2, all other fluids including steam. Categories are SEP (sound engineering practice) and for ascending levels of hazard, I, II, III or IV. All valves designated as SEP do not bear the CE mark nor require a Declaration of Conformity.

Categories I, II, III or IV carry the CE mark and require a Declaration of Conformity

(Note- all valves up to and including 25mm (1") having a maximum allowable pressure greater than 0.5 bar are designated SEP regardless of fluid group).

THE ATEX Directive 94/9/EC

These globe valves are excluded from the ATEX Directive since they have no source of ignition, should not be installed in potentially explosive atmospheres and should only transport Group 2 non-hazardous liquids.

PRODUCT LIFE CYCLE

The life of the valve is dependent on its application, frequency of use and freedom from misuse.

The properties of the fluid being transported such as pressure and temperature must be taken into account to avoid premature failure.

Other factors to be considered are the electrolytic interaction between dissimilar metal used in the system, dezincification and stress corrosion cracking occurring on chilled water service.

Before commissioning a system, it should be flushed to eliminate debris and chemically cleaned as appropriate to eliminate contamination, all of which will prolong the life of the valve.



General Suppliers

Cast Iron Globe Valve - BS 5152 PN16 **MV50-1211**

Installation & Maintenance Instructions

LIMITS OF USE

These products are categorized as SEP for Group 2 Liquid, but are not necessarily suitable for all fluids in this group.

These valves shall not use on Group 2 Gases and Group 1 Liquids.

Operating pressures and temperatures

Maximum non shock pressure and temperature range:

16 bar from -10°C to 100°C

11.8 bar at 230°C

Water hammer and other shock conditions should be avoided. Not suitable for fatigue loading, creep conditions, fire testing, fire hazard environment, corrosive service or transporting abrasive solids.

Warning: Care should be taken when operating the valve, at the maximum operating temperatures, to avoid severe burns to the skin.

PRESSURE / TEMPERATURE RATING

These valves must be installed in a piping system where the normal pressure and temperature do not exceed the above ratings.

If system testing will subject the valve to pressures in excess of the working pressure rating, this should be within the test pressure for the body with the valve in the open position.

If the limits of use specified in these instructions are exceeded or if the valve is used on applications for which it was not designed, a potential hazard could result.

LAYOUT AND SITING

It should be considered at the design stage where valves will be located to give access for operation, adjustment, maintenance and repair.

The preferred installation orientation is;

- Horizontal pipe work with stem vertical - valves should not be installed with the stem horizontal as this may impair its sealing capability.



General Suppliers

Cast Iron Globe Valve - BS 5152 PN16 **MV50-1211**

Installation & Maintenance Instructions

- Vertical pipe work with stem horizontal.

INSTALLATION

Prior to installation, a check of the identification plate and body marking must be made to ensure that the correct valve is being installed.

Valves are precision manufactured items and as such, should not be subjected to misuse such as careless handling, allowing dirt to enter the valve through the end ports and excessive force during hand wheel operation.

Valves and adjoining pipe work must be provided with adequate support to avoid inducing bending stresses into the valve body, which will impair its performance.

Immediately prior to valve installation, the pipe work to which the valve is to be fastened should be checked for cleanliness and freedom from debris. Valve end protectors should be removed immediately prior to installation.

The direction arrow cast on the body must be coincident with the direction of flow in the pipeline.

Valves should not be lifted using the hand wheel or stem, use the correct slings.

Check the surface finish and condition of the gasket contact face on both the valve and pipe work since damage can cause leakage if not rectified.

Gaskets should be suitable for the maximum operating conditions.

Care should be taken to align the flanges being assembled.

During assembly bolts should initially be hand tightened sequentially to make the initial contact ensuring gaskets are concentric with the valve ports and that the flanges are parallel.

Finally tighten the bolts gradually and uniformly in an opposing sequence to prevent bending one flange relative to the other, particularly on flanges with raised faces.

Parallel alignment of flanges is especially important when assembling between exist flanges.

Flanged joints depend on compressive deformation of the gasket material to achieve a seal.

After installation, the valve may be opened and closed fully to confirm satisfactory operation.



General Suppliers

Cast Iron Globe Valve - BS 5152 PN16 MV50-1211

Installation & Maintenance Instructions

It is recommended that valves installed on end of line service and unused for prolonged periods should be fitted with a blank flange.

OPERATION

Open the valve by rotating the hand wheel anticlockwise until a positive stop is felt. When fully open it is recommended to close the valve by $\frac{1}{2}$ a turn.

Close the valves by rotating the hand wheel clockwise until a positive stop is felt.

It may not be possible to isolate the larger sizes

Wheel keys or similar devices should not be used.

The operator should use suitable hand protection at extreme temperature conditions.

MAINTENANCE

The valve should be at zero pressure and ambient temperature prior to any maintenance.

A full risk assessment and method statement must be compiled prior to any maintenance. Use only correct fitting tools and equipment.

The valve should be included in a planned maintenance programme to identify any leakage at an early stage and rectified before it becomes serious

These globe valves should not normally require any maintenance, apart from periodic inspection and adjustment of the gland.

When no further adjustment is left partially repack or fully replace the existing packing depending upon the amount of packing in the stuffing box or severity of the leakage.

Using a sharp pointed tool, lift out the existing packing and ensure the stem and stuffing box are clean & free from debris. Take care not to damage the stem or stuffing box.

Fit genuine Maplef packing into the stuffing box and press down firmly. Re-fit the gland, hand wheel and nameplate and confirm stem resistance while operating the valve.

**Suit420, 145 Chadwick Court, North
Vancouver,
BC V7M 3 K 1, Canada
Phone: +1 778 945 3014
Cell: +1 604 339 6761
Info@maplefvalves.ca
www.maplefvalves.ca**