

Model: MV-MG322 INDICATOR POST Underground Type




FEATURES / CHARACTERSTICS

Fusion bonded coating comply with AWWA C550

MATERIAL SPECIFICATIONS

DET	QTY	PARTS	MATERIAL
1	1	Locking Wrench	ASTM A536
2	1	Operating Nut	CF8/ASTM B62
3	2	Bolt	ASTM A105
4	2	Nut	ASTM A105
5	2	Flat Washer	ASTM A105
6	1	Shap Ring	AISI 606
7	1	Taget Carrier Nut	ASTM B62
8	4	Target	ASTM B108
9	4	Bolt	ASTM A105
10	4	Flat Washer	ASTM A105
11	2	Window Gland	ASTM A307B
12	2	Window Glass	LEXAN-UN STABILIZE
13	4	Gasket	EPDM
14	4	Bolt	ASTM A105
15	4	Spring Washer	ASTM A105
16	1	Nut	ASTM A105
17	6	Body	ASTM A536
18	6	Bolt	ASTM A105
19	1	Nut	ASTM A105
20	4	Base Flange	ASTM A126B
21	8	Bolt	ASTM A105
22	1	Nut	ASTM A105
23	1	Crane Coupling	ASTM A536
24	1	Cotter Pin	AISI 304
25	1	Stand Pipe	ASTM A536
26	1	Stem 1" Square	AISI 1045
27	1	Plug	AISI 304
28	1	Top Cover	ASTM A126B
29	1	Screw	AISI 304
30	1	Lock Nose	ASTM A307B
31	1	Reducer	PARTS
32	4	Bolt	ASTM A105
33	4	Nut	ASTM A105
34	1	Wrench Nut	ASTM A536
35	1	Washer	AISI 304
36	1	Hex. Socket Cap Screw	AISI 304
37	4	Spring Washer	AISI 304





FIELD ADJUSTMENT

- 1. Remove the top section from the top of the Indicator Post assembly.
- 2. Cut the required length off the bottom of the Standpipe for the Ground Line to match up with Standpipe Ground Line mark.
- 3. Set the "OPEN" and "SHUT" targets for the appropriate valve size.
- 4. Reattach the Top Section to the top of the Indicator Post assembly.
- 5. Design and dimensions are subject to change without notice